

WHO International Scheme to Evaluate Household Water Treatment Technologies

AquaPak

Product evaluation report

WHO performance classification	Comprehensive protection Three-star ($\star \star \star$)	
Manufacturer	Solar Solutions LLC 10080 Willow Creek Road San Diego CA 92131 United States www.solarcleanwatersolution.com	
Evaluation procedure	Full laboratory testing	
WHO report issue date	Round II, 2018	
WHO reference number	20/07/2015-R2-22	

Summary of evaluation

This report summarizes the results of laboratory testing of a solar pasteurization bag known by the tradename 'AquaPak', under Round II of the World Health Organization (WHO) International Scheme to Evaluate Household Water Treatment Technologies (the Scheme). Testing followed the requirements of the WHO protocol for solar (ultraviolet and heat) disinfection technologies. Testing investigated the ability of the device to inactivate bacteria, viruses and protozoa. Based on the evaluation results, the AquaPak meets WHO performance criteria and is classified as providing three-star ($\star \star \star$) *Comprehensive protection* against bacteria, viruses and protozoa.

Background

Evaluation under the Scheme is based on performance criteria set out in *Evaluating Household Water Treatment Options: Health-based targets and microbiological performance specifications* (WHO, 2011). The criteria were determined by applying quantitative microbial risk assessment (QMRA) methods outlined in the WHO *Guidelines for Drinking-water Quality* (2017) and set out log₁₀ reduction targets against bacteria, viruses and protozoa, as shown in Table 1.

Performance classification	Bacteria (log ₁₀ reduction required)	Viruses (log ₁₀ reduction required)	Protozoa (log ₁₀ reduction required)	Interpretation (with correct and consistent use)	
***	≥ 4	≥ 5	≥4	Communication and a disc	
**	≥2	≥3	≥2	Comprehensive protection	
*	Meets at least 2-star (★ ★) criteria for two classes of pathogens			Targeted protection	
_	Fails to meet criteria for 1-star (\star)			Little or no protection	

Table 1. WHO performance criteria for household water treatment technologies

Product description

The AquaPak is a pasteurization device that uses solar and thermal energy. The device consists of a 5 L polyethylene bag with a bubble pack layer of clear plastic on the front and a black plastic layer on the back. When the device is exposed to sunlight, the black layer radiates heat, which pasteurizes water in the bag. The bubble pack layer insulates the bag. The AquaPak has a 'treatment complete' indicator, a glass cap filled with orange-coloured wax that melts to a clear colour at 65 °C when the water has been sufficiently treated. The full description, illustrations and use instructions can be found at: www.solarcleanwatersolution.com.

Test methods

Product-specific test plan: A product-specific test plan was developed based on the manufacturer's instructions for use; the Harmonized Testing Protocol: Technology Non-Specific V 2.0 (WHO, 2018a); and the Solar (UV and Heat) Disinfection Technology Protocol V 2.0 (WHO, 2018b). Testing was conducted at a WHO-designated laboratory, KWR Watercycle Research Institute, in the Netherlands.

Test organisms: Evaluation of the AquaPak investigated its performance in reducing bacteria, viruses and protozoa. The test organisms were *Escherichia coli* (*E. coli*); coliphages MS2 and phiX174; and *Cryptosporidium parvum* (*C. parvum*) infectious oocysts, respectively.

Test waters: The device was tested in two simulated natural waters: General Test Water (GTW), simulating high quality groundwater, and Challenge Test Water (CTW), simulating surface water. Details on the physicochemical characteristics of the test waters are provided in the Solar (UV and heat) Disinfection Technology Protocol (WHO, 2018b)

Test set up: Three production units were used in the test, with daily test volumes of 3-5 L. The units were operated according to the manufacturer's use instructions. Solar and UV irradiance were simulated using the Atlas SUNTEST XXL instrument. Pretreatment and posttreatment water grab samples were analysed using methods identified in the product-specific test plan. Testing was conducted over four days (GTW on days 1 and 2; CTW on Days 3 and 4), resulting in a total of 12 sample points for each organism (i.e. 2 days \times 2 test waters \times 3 test units).

Results

Fig. 1 presents the mean log₁₀ reductions for the three units in GTW and CTW. All GTW and CTW characteristics were within specifications.




Fig. 1 Performance across test units¹

The AquaPak achieved mean log₁₀ reductions of >7.3 for E. coli, >5.7 for MS2; >6.3 for phiX174; and >4.3 for *C. parvum*.

Interpretation and application of results

Performance is classified in three ascending tiers of performance: \star (one-star); $\star \star$ (two-star); and $\star \star \star$ (three-star), as shown in Table 1. Both three- and two-star products are classified as providing *Comprehensive protection* against all three microbial groups. One-star products are those that meet performance targets for only two of the three microbial groups, and are classified as providing *Targeted protection*.

Each production unit should consistently meet or exceed the performance target for each microbial group, and in both test waters (GTW and CTW). However, a maximum deviation of $0.2 \log_{10}$ is acceptable for 25% of sample points at the two-star performance tier, and $0.4 \log_{10}$ at the three-star performance tier². This means that for classification as a two-star product, up to three of the twelve sample points can achieve a reduction of 1.8 \log_{10} for bacteria or protozoan cysts (instead of $2 \log_{10}$), or 2.8 \log_{10} for viruses (instead of $3 \log_{10}$). Each phage is treated separately for evaluating acceptable allowance, and the overall claim for viruses is based on the lower performing phage.

¹ The maximum microbial reduction that can be demonstrated is limited by the pretreatment challenge concentration delivered. For each organism tested, the pretreatment concentration must be sufficient to allow for the demonstration of the performance targets in the table showing the performance criteria. Due to the complexity of using viable organisms, there may be variation in these pretreatment concentrations above what is sufficient, which may lead to demonstrated reductions reported that far exceed the performance targets. However, the emphasis is on whether the performance target has been met and not the extent by which the target was exceeded.

² These cut-off values were determined using QMRA modelling and selecting ranges that still resulted in appreciable health gains within a specific performance tier.

Performance classification

The AquaPak met the $\star \star \star$ (three-star) performance targets for bacteria, viruses and protozoa. It is classified as providing Comprehensive protection ($\star \star \star$).

Considerations for product selection

	Microbial conditions	Effective against bacteria, viruses and protozoa; can be used under all microbial water quality conditions
	Physico-chemical water characteristics	Can be used in both turbid and non-turbid water; includes a pre-filter to help reduce turbidity
	Environmental conditions	Relies on solar / thermal energy; most appropriate for sunny climates
Constant of the second	Product information and labelling	Check that product is appropriately labelled and has clear instructions for use

References

WHO (2011). Evaluating household water treatment options: health-based targets and microbiological performance specifications. Geneva: World Health Organization (http://www.who.int/water_sanitation_health/publications/household_water/en/).

WHO (2017). Guidelines for drinking-water quality, fourth edition. Incorporating the first addendum. Geneva: World Health Organization (https://www.who.int/water_sanitation_health/publications/dwq-guidelines-4/en/).

WHO (2018a). Harmonized Testing Protocol: Technology non-specific version 2.0. Geneva: World Health Organization (http://www.who. int/water_sanitation_health/water-quality/household/household-water-treatment-scheme-resources/en/).

WHO (2018b). Solar (UV and heat) Disinfection Technology Protocol version 2.0. Geneva: World Health Organization (http://www.who. int/water_sanitation_health/water-quality/household/household-water-treatment-scheme-resources/en/).

Disclaimer

Reference to any company or product in this report, particularly those listed in any of the figures and tables, does not constitute an endorsement, certification or warranty of fitness by WHO of such company or product for any purpose, and does not imply any preference over companies or products of a similar nature that are not mentioned.

WHO does not furthermore warrant that: any products included in the figures and tables are of acceptable quality, have obtained regulatory approval in any country, or that their use is otherwise in accordance with the national laws and regulations of any country, including but not limited to patent laws. Evaluation under the Scheme is intended to guide UN Member States and procuring UN agencies in the selection of household water treatment (HWT) technologies. Inclusion of any products in this report, particularly in any of the figures and tables listed in the report does not furthermore imply any approval by WHO of these products (which is the sole prerogative of national authorities).

The results in this report reflect the performance level which the product was found to meet at the time of testing. WHO cannot represent that the products reported herein will continue to meet the stated performance levels. Furthermore, the results contained in this report may not be used by manufacturers, suppliers or any other parties for commercial or promotional purposes.



For more information, contact:

World Health Organization Water, Sanitation, Hygiene and Health Unit Department of Public Health, Environmental and Social Determinants of Health 20, Avenue Appia 1211 Geneva 27 Switzerland Email: hhwater@who.int

http://www.who.int/water_sanitation_health/water-quality/household/ scheme-household-water-treatment/en/